



Toshiba
 CT- 10000
 430/5300/6200
 7000/7110
 Cód. Emb.
 090908 012/048

Toshiba



Toshiba
 CT3400/3700/9736
 TS149
 Cód. Emb.
 338501 016/064

Toshiba



Semp Toshiba
 Para toda linha LUMINA
 Cód. Emb.
 160078 020/080

Semp Toshiba



Aiwa
 AR145/205 - RCZVT
 Cód. Emb.
 115139 010/040

Aiwa



Philco
 PCR43/44/PCM1444
 2046/2700/2952
 Cód. Emb.
 573132 015/060

Philco



Philco
 (VCR / TV) 1410/12/2010
 PTVR 1400
 Cód. Emb.
 338401 016/064

Philco



Philco
 Universal PCR31
 Cód. Emb.
 338301 015/060

Philco



Philco
 PC20R38,38/42-2136
 2142/1436/1438/1444
 1446/2036/2038/2044
 2046/PVM2160/2162
 2900/2901/2920P
 TP1450/1453/2042
 2063/2976
 Cód. Emb.
 409100 015/060

Philco



LG
 CP14B85/86/14J52
 14K85/14Q90/20D85
 Cód. Emb.
 203256 010/040

LG

Controle remoto



CCE
1401/1492/2201/2092

Cód. Emb.
339101 020/080

CCE



CCE
HPS 1470/1480/1490
2080/2081/2980/2981
14R

Cód. Emb.
870495 012/048

CCE



CCE
BLUE SKY 14/20 BLK RC27

Cód. Emb.
339001 016/064

CCE



Philips/CCE
27427/1310/1311/1312/1340
1341/1342/1410/1411/1412
1440/1451/1452
HPS - 1470/81/ 90

Cód. Emb.
794766 012/048

Philips/CCE



Philips
RC 0768 SMART/Pt14/20
21/29 TODOS GL / GR

Cód. Emb.
932924 020/080

Philips



Philips Smart
1014/1015/1018/1019/1049
1313 / 1314

Cód. Emb.
339201 016/064

Philips smart



Philips
14PT218/14PT519/20PT519
21PT639/29PT458 /2PT558

Cód. Emb.
160105 020/080

Philips



Philips
Cód. Emb.
338701 015/060

Philips



Philips
3010 For all Philips Line

Cód. Emb.
277264 020/080

Philips



Gradiente GT
1410/1415/2010/2015
14C5170

Cód. 390576 **Emb.** 016/064

Gradiente



Gradiente
JVC HRM 277S/299S
GT 2825 RM C538

Cód. 784405 **Emb.** 020/080

Gradiente



Sharp
JVC HRM 277S/299S
GT 2825 RM C538

Cód. 142536 **Emb.** 015/060

Sharp



Sharp
1450/95- 2050/95

Cód. 339301 **Emb.** 016/064

Sharp



Sharp
001600/C-1438/1413/1417
2038

Cód. 652813 **Emb.** 015/060

Sharp



Sharp
1453/2057/20ST57/1457
C-14/29ST54/TV-VCR

Cód. 867642 **Emb.** 010/040

Sharp



Mitsubishi
TC1492/1498/1499/2098
2099/2198/20A

Cód. 396725 **Emb.** 016/064

Mitsubishi



Mitsubishi
TC1441/1631/2031/2041

Cód. 860531 **Emb.** 015/060

Mitsubishi



Diamond Vision
MITSUBISHI 2018

Cód. 338601 **Emb.** 016/064

Mitsubishi

Controle remoto




Mitsubish
TC 1409/1418/2009
2918PS/2990

Cód. Emb.
160108 010/040

Mitsubishi



Panasonic
TC14A4/20A4/29-29V50

Cód. Emb.
566082 016/064

Panasonic



Panasonic TC
14A7/20A7/29A10/29A9
29A11/29A12/29G91

Cód. Emb.
286373 010/040

Panasonic



Sanyo
29LB/29LB1/AVM1440
2040/29LH

Cód. Emb.
338901 016/064

Sanyo



Century
Receptor de Parabólica
USR 1850/USR 1900

Cód. Emb.
160071 012/096

Century



Century
Receptor satélite

Cód. Emb.
800352 016/064

Century



Orbisat
Receptor de parabólica
p/ toda linha 2.000

Cód. Emb.
160051 016/064

Orbisat



Kirey
FisrLine KTV
1414/2020/2929
FIRSTILINE/CROW
PACIFIC/AUDIONAK/AKIO

Cód. Emb.
829037 016/064

Kirey



GoldStar
FS-222 toda linha
LG GoldStar, Gradiente
GT2022

Cód. Emb.
212165 012/048

Goldstar



NET (PR, MG, RJ)
TVA (SP, MG, RJ)

Cód. Emb.
295895 020/080

NET/TVA



DVD Britânia

Cód. Emb.
800353 010/040

DVD Britânia



Controle universal DVD

Cód. Emb.
700012 006/024

Universal DVD



UNIVERSAL 3 em 1
Quase todas as marcas

Cód. Emb.
156985 010/020

Universal



Universal 7 em 1

AIWA/ GOLDSTAR/ GEC/ ITACHI
ITT- NOKIA/ KENWOOD/ MITSUBISHI/ NEC
NORDMEND/ PANASONIC/ PHILIPS/ PHILCO
PIONNER/ QUELLE/ RANK/ SABA/ SAMSUNG
SANYO/ THOMSON/ ZENITH

Cód. Emb.
717100 008/032

Universal



Universal 10 em 1

AIWA/ AKAI/ DAEWOO/ HITACHI/
ITT- NOKIA/ JVC/ KENWOOD/ MITSUBISHI
NEC/ NORMANDE/ ORION/ PANASONIC
PHILIPS/ PHILCO/ PIONEER/ QUELLE/ SABA
SAMSUNG/ SANYO/ SCHNEIDER/ SHARP
SIEMENS/ SONY/ THOMSON/ TOSHIBA
YAMAHA

Cód. Emb.
101000 012/024

Universal